Set Associative Mapping-

In k-way set associative mapping,

- Cache lines are grouped into sets where each set contains k number of lines.
- A particular block of main memory can map to only one particular set of the cache.
- However, within that set, the memory block can map to any freely available cache line.
- The set of the cache to which a particular block of the main memory can map is given by-

Cache set number

= (Main Memory Block Address) Modulo (Number of sets in Cache)

Division of Physical Address-

In set associative mapping, the physical address is divided as-

Tag	Set Number	Block / Line Offset
-----	------------	---------------------

Division of Physical Address in K-way Set Associative Mapping

Set Associative Cache-

Set associative cache employs set associative cache mapping technique.

The following steps explain the working of set associative cache-


After CPU generates a memory request,

- The set number field of the address is used to access the particular set of the cache.
- The tag field of the CPU address is then compared with the tags of all k lines within that set.
- If the CPU tag matches to the tag of any cache line, a cache hit occurs.

- If the CPU tag does not match to the tag of any cache line, a cache miss occurs.
- In case of a cache miss, the required word has to be brought from the main memory.
- If the cache is full, a replacement is made in accordance with the employed replacement policy.

Implementation-

The following diagram shows the implementation of 2-way set associative cache-



(For simplicity, this diagram shows does not show all the lines of multiplexers)

The steps involved are as follows-

Step-01:

 Each multiplexer reads the set number from the generated physical address using its select lines in parallel. To read the set number of S bits, number of select lines each multiplexer must have = S.

Step-02:

- After reading the set number, each multiplexer goes to the corresponding set in the cache memory.
- Then, each multiplexer goes to the lines of that set using its input lines in parallel.
- Number of input lines each multiplexer must have = Number of lines in one set

Step-03:

- Each multiplexer outputs the tag bit it has selected from the lines of selected set to the comparators using its output line.
- Number of output line in each multiplexer = 1.

<u>UNDERSTAND</u>

It is important to understand-

- A multiplexer can output only a single bit on output line.
- So, to output one complete tag to the comparator,
 Number of multiplexers required = Number of bits in the tag
- If there are k lines in one set, then number of tags to output = k, thus-Number of multiplexers required = Number of lines in one set (k) x Number of bits in the tag
- Each multiplexer is configured to read the tag bit of specific line at specific location.
- So, each multiplexer selects the tag bit for which it has been configured and outputs on the output line.
- The complete tags as whole are sent to the comparators for comparison in parallel.

Step-04:

- Comparators compare the tags coming from the multiplexers with the tag of the generated address.
- This comparison takes place in parallel.
- If there are k lines in one set (thus k tags), then-

Number of comparators required = k

Size of each comparator = Number of bits in the tag

- The output result of each comparator is fed as an input to an OR Gate.
- OR Gate is usually implemented using 2 x 1 multiplexer.
- If the output of OR Gate is 1, a cache hit occurs otherwise a cache miss occurs.

Hit latency-

• The time taken to find out whether the required word is present in the <u>Cache</u> <u>Memory</u> or not is called as **hit latency**.

For set associative mapping,

Hit latency = Multiplexer latency + Comparator latency + OR Gate latency

Important Results-

Following are the few important results for set associative cache-

- Block j of main memory maps to set number (j mod number of sets in cache) of the cache.
- Number of multiplexers required = Number of lines in one set (k) x Number of bits in tag
- Size of each multiplexer = Number of lines in one set (k) x 1
- Number of comparators required = Number of lines in one set (k)
- Size of each comparator = Number of bits in the tag
- Hit latency = Multiplexer latency + Comparator latency + OR Gate latency